If there's a spill, ask yourself... **WWYD***?

Is anyone hurt? Get help for the injured person(s)

What was spilled & how much? IMPORTANT: Get help from senior staff or neighbors

if you are not sure how bad it is

Very Hazardous or Large Spill

Mildly Hazardous or Small Spill

Notify neighbors Close off area Evacuate (if needed)	Contain	Get spill kit Put on disposable PPE Isolate/surround spill area
	Clean ASK for help from others!!	Get SDS for the spilled item Get UCD SafetyNets # 13, 127 Call (530) 752-1493** for advice 8am-5pm, M-F only Neutralize spill Decontaminate area
	Dispose	Put contaminants in container (include used PPE & absorbents) Label waste container Put in hazardous disposal area
Call 911 & Call 55 Call your Pl Wait for help to arrive	Report	Tell your PI & UCD department Tell Elsie & Sherry Make Shriners report

** People working after hours should be trained to clean minor spills alone

Safety Data Sheet (SDS) sources 1. Shriners SDS Phone Service: 1-888-362-7416

2. RightAnswer.com

(https://ehs.ucop.edu/sds/sdsprovider/rightAnswer)

RightAnswer is a source of safety information, including the RTECS© Registry. **Note:** Single-sign on enabled with your UCTrust credentials.

3. Google

Google SDS Search (https://ehs.ucop.edu/sds/#/msdscse)

A customized Google search focusing on returning Safety Data Sheets using your search terms.

Chemical Health and Safety Information Pubchem 1.

PubChem Laboratory Chemical Safety Summary

https://pubchemdocs.ncbi.nlm.nih.gov/lcss

PubChem Laboratory Chemical Safety Summary (LCSS) contains pertinent chemical hazard and safety information.

ChemSpider

2. Search and Share Chemistry

ChemSpider http://www.chemspider.com/

ChemSpider is a free chemical structure database providing fast text and structure search access to over 34 million structures from hundreds of data sources.

3. National Library of Medicine ChemID*plus*

http://chem.sis.nlm.nih.gov/chemidplus/

TOXNET® (TOXicology Data NETwork) is a group of databases covering chemicals and drugs, diseases and the environment, environmental health, occupational safety and health, poisoning, risk assessment and regulations, and toxicology.



Published on UC Davis Safety Services (<u>https://safetyservices.ucdavis.edu</u>)

Guidelines for Chemical Spill Control

SafetyNet #: 13

General Steps To Follow

- When 1 pint or more of a hazardous material or any amount of an extremely toxic substance is spilled or when in doubt, call the UC Davis Fire Department at 9-1-1. Evacuate the room, close the door, and wait for emergency personnel.
- 2. If the substance spilled is flammable, turn off all ignition sources before securing the room.
- 3. In case of chemical contact with skin or eyes, flood the affected area immediately with water; continue for at least 15 minutes. Seek medical assistance at Occupational Health Services located at the Cowell building or the Student Health and Wellness Center for skin irritation, contact with an extremely toxic substance, any eye injury, or any adverse reaction.
- 4. All contaminated clothing must be removed immediately. Clothes must be laundered before reuse or disposed of as hazardous waste.
- 5. When incidental to one's duties, small spills (1 pint or less) may be cleaned up by laboratory personnel. It is good laboratory practice to keep spill absorbents on hand. A good, general purpose spill absorbent is available from the Storehouse (Fisher Scientific, Cat. No.: NC9571649, DRIZORB Absorbent). Spill cleanup kits for solvents, acids, bases (caustics), mercury, hydrofluoric acid, and others are commercially available from sources such as J.T. Baker and Lab Safety Supply.
 - Most strong acids may be absorbed and then neutralized with aqueous solutions of sodium bicarbonate, calcium hydroxide (slaked lime), or sodium carbonate (soda ash). (Note: DO NOT attempt to absorb hydrofluoric acid (HF). Skip this step and neutralize immediately only if you are familiar with proper neutralization procedures for HF; otherwise, return to step one.)
 - 2. Caustic solutions and flammable liquids may be absorbed with an inert absorbent.
 - 3. DO NOT attempt to blot cryogenic liquid spills with unprotected hands. Evacuate the space and allow the liquid to evaporate. If the cryogenic fluid evaporates to a flammable, toxic or asphyxiating gas, follow procedures (1) and (2) for large spills.
 - 4. Formaldehyde spills may be absorbed with an inert absorbent.
 - 5. For mercury spills, see <u>SafetyNet #16</u> [1], "Guidelines for Mercury Spill Control", for more information.

- 6. Solid spills are not usually emergencies. If the material spilled is toxic, use dampened cloths or paper towels to transfer it to plastic bags. Brushing dry material may cause dust to become airborne.
- 6. All absorbed spill material must be collected in double plastic bags or plastic containers with secure lids and disposed of as hazardous waste. See <u>SafetyNet #8</u> [2], "Guidelines for Disposal of Chemical Waste" for more information. If the absorbent has been used for a flammable or volatile compound, it must be stored in a well-ventilated area away from sources of ignition while awaiting pickup. A fume hood is a good temporary storage area.

Contact

Research Safety

researchsafety@ucdavis.edu 530-752-1493 FAX: 530-752-4527

More information https://safetyservices.ucdavis.edu/research-safety-staff-listing [3]

Related content

- 1. Guidelines for Mercury Spill Control
- 2. Chemical Waste Disposal Guidelines

Copyright @2015 The Regents of the University of California, Davis campus. All rights reserved.

Source URL (modified on 01/26/17 02:06pm): https://safetyservices.ucdavis.edu/safetynet/guidelines-chemical-spill-control

Links

- [1] https://safetyservices.ucdavis.edu/safetynet/guidelines-mercury-spill-control
- [2] https://safetyservices.ucdavis.edu/safetynet/guidelines-disposal-chemical-waste
- [3] https://safetyservices.ucdavis.edu/research-safety-staff-listing

SHRINERS HOSPITALS FOR CHILDREN	
Northern California	

FINVIRUNVIENT OF CARE TOLICIES & TROOLDORD	ENVIRON	MENT OF	CARE POLICI	ES & PROCEDURES
--	---------	---------	-------------	-----------------

POLICY NUMBER: 3.17

EFFECTIVE DATE: 1/11

CHEMICAL SPILL (CODE WHITE)

DEPARTMENT DISTRIBUTION: All

REVIEW/REVISION DATE: 12/13, 10/16

NEXT REVIEW DATE: 10/19

APPROVED BY:

Manager: Facilities

Safety Coordinator

Chair, EOC Committee

I. POLICY

This policy will provide a course of action employees may take in the event of a chemical spill (Code White).

III. PROCEDURE

- A. Immediately upon identifying a hazardous chemical spill in the facility, ensure the safety of the area by alerting people in the area, isolate the spill by closing doors or coning the area and notify the Receptionist by dialing "55". The Receptionist will announce "CODE WHITE" three (3) times.
- B. The following contacts will be able to provide clean-up assistance:

Safety Coordinator 453-5044 Facilities Department 453-2070 or x2074 Sacramento Fire Department 9-1-1 Sacramento County Environmental Management Department – 875-6900

- C. The Safety Coordinator will:
 - a. Evaluate effected parts of the facility.
 - b. Identify the amount and character of any chemical released.
 - c. Assess the hazards to human health and the environment.
 - d. Take all reasonable measures to limit the extent of the incident.
 - e. Notify the Administrator or Administrator On-Call.

- f. After the emergency has ended, provide for safe storage or disposal of all hazardous wastes generated.
- g. Assure that all safety equipment is returned to usable condition.
- h. Maintain records of the incident and complete an Occurrence Report.
- D. If it is determined that the Hospital Command Center (HCC) must open, the Incident Commander will:
 - a. Initiate the evacuation of effected parts of the facility as necessary.
 - b. If evacuation of neighboring areas is necessary, notify the Sacramento Fire Department at 9-1-1.
 - c. When the incident has ended, contact the Receptionist to announce the ALL CLEAR.
 - d. Hold a debriefing and assist the Safety Coordinator complete the Occurrence Report.
- E. If a spill at SHCNC requires outside assistance, the Sacramento City Fire Department or Sacramento County will be the Incident Commander. The Security Department will provide scene security, traffic control, evacuations, etc., as necessary. The Safety Coordinator and the Facilities Department will provide technical advice and assistance to the Incident Commander.

III. HAZARD MITIGATION

- A. The Safety Coordinator, in consultation with the Administrator or Administrator On-Call (AOC) and other emergency responders, must make decisions based on the specific emergency situation.
 - a. Evacuation
 - i. The Safety Coordinator will quickly determine if evacuation is necessary. If so, the following procedures will be followed:
 - 1. Each department that is required to evacuate will relocate to the nearest uncompromised smoke compartment.
 - 2. The Safety Coordinator will coordinate checking of the areas to ensure all personnel have left. Only authorized public safety personnel will be allowed in the area. The Security Department will establish a perimeter at an appropriate distance around the incident as required.
 - 3. The Department Manager or designee will account for all staff working in the evacuated area and will forward information to the HCC. The name(s) of any missing personnel will be given to the HCC.
 - 4. No one may re-enter the incident area until the "ALL CLEAR" is issued by the HCC.
 - b. Medical Treatment
 - i. Anyone injured in a chemical incident must be decontaminated prior to transportation, if possible. The specific steps to be followed will depend on the nature of the chemical and the severity

of the victim's injuries. Risk to the victim must be minimized while controlling any possible spread of chemical contamination. The Sacramento Fire Department will perform decontamination procedures in the Clinical Laboratory, which is equipped with a deluge shower facility.

- c. Evacuation of Nearby Neighbors
 - i. The decision to evacuate any neighboring residences will be made by the Fire Department Incident Commander.
- d. Fire In case of fire, use the "R.A.C.E." fire procedures listed in EOC Policy 4.2 Fire Alarm Response (Code Red).
- B. Hazardous Materials Spill Within The Hospital
 - a. Follow Procedure instructions above
 - b. Do not enter the spill area unless fully protected with proper Personal Protective Equipment PPE.
 - c. If possible, clean up the spill as follows:
 - i. Clean and remove containers and contaminated material.
 - ii. Collect free-flowing liquids, return them to appropriate containers.
 - iii. Use an appropriate pump, if available.
 - iv. Absorb any remaining liquid with absorbent compound.
 - v. Sweep up the absorbent compound with a stiff broom, placing collected material in a lab pack.
 - vi. Spread a second application of absorbent; sweep up with a stiff broom, and place in a pack.
 - vii. Place contaminated materials in spill approved disposal containers.
 - viii. Properly label all containers.
 - d. Elemental mercury spills:
 - a. Call 9-1-1 or 875-6900 (Sacramento County Environmental Management Department)
 - i. An Occurrence Report will be completed.
 - e. If the spill is unmanageable, call 9-1-1 or 875-6900 for clean-up assistance
 - i. The AOC should be contacted (Pager 590-6107)
 - ii. If after actions were taken to contain and clean-up the spill, the release still poses either a present or potential threat to the health and safety of people or to property or the environment, notify the California Office of Emergency Services 916-845-8510
 - iii. A written report will be sent to the California Department of Toxic Substances Control at P.O. Box 400 Sacramento, CA 95812 within fifteen (15) days after the incident when the release of a hazardous material posed a hazard or potential hazard to human health and safety, property, or to the environment.
 - f. Flash Flood
 - i. Secure all hazardous materials containers at the facility.
 - ii. Close doors to prevent hazardous materials from floating away.
 - iii. Evacuate all personnel to higher ground. Follow the instructions of local emergency departments for evacuation routes.

- iv. Notify the Administrator or Administrator on call (AOC).
- g. Earthquake
 - i. Cease all use of hazardous materials immediately.
 - ii. Check all hazardous material storage areas for damage.
 - iii. Follow procedures for spills as outlined above.

IV. COORDINATION AGREEMENTS

- B. SHCNC has made arrangements for assistance in emergency situations. The following agencies received a copy of the Contingency Plan:
 - a. Sacramento Fire Department 1231 I Street, Suite #401 Sacramento, CA 95814-2979 Phone Number: 9-1-1

 b. Sacramento County Environmental Management Department Environmental Compliance Division 10590 Armstrong Ave, Suite A Mather, CA 95655-4153 County Communication Line – 875-6900

IX. REVIEW

A. The EOC Committee will review the Contingency Plan and amend it whenever there has been an emergency requiring implementation of the plan, or the potential for release, fire or explosion increases.



Published on UC Davis Safety Services (<u>https://safetyservices.ucdavis.edu</u>)

Biological and Biohazardous Spill Response SafetyNet #: 127

This Safety Net outlines the steps to take after a spill of any infectious agent or recombinant DNA material has occurred in your laboratory or in nearby areas such as in a corridor. Although any laboratory that uses hazardous materials is required to have an appropriate spill clean-up kit available and to provide spill clean-up training, responding effectively and safely to a spill requires judgment and risk assessment. If you are not comfortable with the situation or are not confident of your abilities (even if you are thoroughly trained), or if you think that clean-up might entail unacceptably elevated risk, discuss the spill with the Biological Safety Office staff at EH&S before going further. No matter what action you decide to take, moderate to high-hazard spills as noted below must be reported to the Biological Safety Office before you attempt to clean them up, and under NIH and UC Davis rules all spills of all biological materials including spills of Risk Group (RG) 1, RG2, or RG3 agents or any recombinant DNA materials must be reported to the Biological Safety Office of the event. You can report the spill by telephone or by using the <u>online system</u> [1].

This SafetyNet constitutes the standard UC Davis biohazardous spill response training document, and includes a risk-related spill response matrix and a spill response instruction summary page intended for laboratory posting. Before posting the matrix and instruction sheets please highlight the matrix as appropriate to the types of biological agents handled in your laboratory.

Spill risk assessment:

Evaluate the spill to determine the level of risk it represents, so that you can decide whether you or anyone in your group has the training, knowledge, and equipment needed to clean up the spill and to decontaminate all contaminated surfaces so that 100% of the spilled material is removed or inactivated. Your risk assessment should also help you to determine whether an immediate response with absorbent material is necessary to prevent the spill from seeping into places that will be particularly difficult to clean. Consider:

- Biohazard potential of the spilled material (Risk Group (RG) classification, agent infectious route, agent infectious dose)
- Spill volume
- Spill location
- Extent of visible spatter (cryptic spatter is likely to be even more extensive)

- Additional risks (e.g., does the spill include broken glass?)
- Skill, experience, and health status of trained personnel
- Availability of Personal Protective Equipment (PPE)

1. Moderate to high-hazard spills that must be reported to the Biological Safety Office *before* clean-up but *after* necessary personal decontamination include:

- Any spill >500 ml
- Any spill from a fermentor at Biological Safety Level 1--Large Scale (BSL1--LS) or above
- Any spill in a Biological Safety Level (BSL) 3 laboratory
- Any viable cultured RG2 agent of any volume outside a biological safety cabinet
- Any viable cultured RG2 agent \geq 10 ml inside a biological safety cabinet
- Any spill of biological or biohazardous materials or agents in a publicly accessible area such as a corridor
- Spills of a RG2 or RG3 agent or rDNA construct inside a centrifuge that occurred during operation, in an unsealed rotor or carrier
- Spills of a RG2 or RG3 agent inside a refrigerator, especially spills discovered when the door is opened
- Any spill for which no person trained to clean up is currently available

Biological Safety Office telephone contact information for immediate assistance:

Spill time and location	Telephone number	Telephone number to callRequest assistance from:			
Normal business hours					
From the Davis or Sacramento	520 752 1402	Piological Safoty Office			
campuses	550 752-1495	Biological Salety Office			
After hours and on weekends					
From the Davis Campus	911 dispatch	EH&S 24/7 on-call			
From the Sacramento Campus	911 dispatch	EH&S 24/7 on-call			
2. Spill kit: a biological or biohazar	dous spill kit should includ	e the following items:			

- Bleach or other approved disinfectant specific to your agents or materials
- Spray bottle
- Appropriate container to dilute disinfectant, if needed
- Gloves (assorted sizes)
- Eye protection/face shield and other appropriate PPE as noted below
- Paper towels (at least one full package)
- Long forceps or egg tongs (or both—egg tongs are better for picking up broken glass, forceps may be better for pushing paper towels into tight corners, and for retrieving disinfectant-soaked paper towels)

- Red biohazard bags or clear autoclave bags, as appropriate for the spilled materials
- Empty, appropriately marked sharps container for disposing broken glass (clear white without biohazard label for RG1 materials, red with a biohazard label for medical waste including human and non-human primate source materials and RG2 and RG3 infectious agents)
- A dust pan and brush for spills of dry RG1 material such as transgenic plants

Store these materials in a container of appropriate size (e.g. Nalgene tub, five-gallon paint bucket) in an easily accessible location, and verify the integrity and completeness of the contents at least twice per year (ensure that the gloves are not degraded, that the disinfectant is not expired, that the spray bottle, paper towels, sharps container, eye protection, and forceps have not been diverted to other uses, etc). Be sure to label the container and the outside of the storage cabinet prominently.

To clean up a biological or biohazardous spill:

First Priority: Assess yourself and other laboratory occupants for potential personal contamination. If any personal contamination with a RG2 or RG3 agent or contaminated material is found or believed to have occurred:

- 1. Remove all contaminated clothing, quickly. Place contaminated clothing in a red biohazard/autoclave bag to be autoclaved later. **Do not contaminate public areas with contaminated clothing**. *In anticipation of such emergencies, the PI should provide a fire protection or other blanket that can be used to cover someone who must remove biohazardous spill-contaminated clothing or who must use an emergency shower following a chemical splash.*
- 2. Flood the skin with flowing water for approximately 15 minutes and wash using soap and water. Do not use hot water and do not scrub so vigorously that you abrade the skin.
- 3. If aerosol formation is believed to have been associated with the incident leave the contaminated area immediately. Post the contaminated area to prevent entry until it is safe.
- 4. Seek medical attention promptly: contact Occupational Health Services (530 752 6051) and EH&S (530 752 1493). On weekends and after normal work hours call 911.
- For eye splashes, hold the eyes open and irrigate with plenty of water at an eyewash station for at least 15 minutes. Seek medical attention promptly: contact Occupational Health Services (530 752 6051) and EH&S (530 752 1493). On weekends and after normal work hours call 911.

Second Priority: Clean up the spill:

- 1. Wear appropriate PPE to clean spills (as detailed in the response matrix that accompanies this SafetyNet).
- 2. If the spill involved broken glass, pick up the large pieces with the forceps or egg tongs and dispose in a hard-walled sharps container. Handle broken glass with care!
- 3. Distribute paper towels around the periphery of the spill, then towards the center. Use the forceps or egg tongs to push paper towels into recesses where spilled material may have

flowed.

- 4. Dilute your disinfectant to the appropriate concentration in a spray bottle (if available).
- 5. When the spill is fully covered with paper towels, spray or very carefully pour 10% bleach or other approved disinfectant on the paper towels. Avoid generating further aerosols or flooding the spill so much that untreated material may flow

6. Allow at least 30 minutes contact time.

- 7. Pick up the paper towels with large forceps or egg tongs and put them in the appropriate waste bag. Change gloves and put used gloves in bag as well. *Avoid direct contact with the contaminated paper towels, even with gloved hands*
- 8. Spray or carefully pour 10% bleach or other approved disinfectant on the surface residue. Wipe up the residue with paper towels and place in appropriate bag. Small bits and pieces of broken glass should be entrained in the wet paper towels and discarded into the waste bag. Pieces too large or heavy to entrain must be discarded in a sharps container.
- 9. Repeat step "8" at least once.
- 10. Seal and transport the waste collection bag to the appropriate autoclave or medical waste accumulation site.
- If broken glass was disposed in a sharps container, seal the container permanently, decontaminate the exterior with the sprayed liquid disinfectant, and transport the sealed container to a medical waste accumulation site or request a sharps pickup on the Safety Services website (Davis campus)
- 12. Clean and disinfect the forceps or egg tongs and any other non disposable items before returning them to the spill kit. If possible, autoclave the forceps or egg tongs before returning them to the kit.
- 13. Report the spill to your supervisor and to the Biological Safety Office if you have not already done so.

Guidelines and rules to help prevent spills:

- Practice manipulations involving biohazardous materials and agents by handling similar volumes of non-hazardous materials with the same tools and containers in the same working environment (e.g., biological safety cabinet) until you are adept and comfortable with the entire procedure.
- Always transport biohazardous materials outside of a biological safety cabinet in secure secondary containment.
- Always use sealed rotors or carriers to spin biohazardous materials in a centrifuge.
- Always store biohazardous liquids in refrigerators in a manner that prevents spillage if the container is tipped (secondary containment is important).
- Always ensure that the bottom drain is closed before working at a biological safety cabinet.
- Always transport biohazardous materials in publicly accessible areas in secondary leakproof containment, with sufficient absorbent material to absorb the entire liquid contents of the primary container. Label secondary containers with the universal biohazard

Tips to help handle spills:

- Study the attached Spill Response Matrix in advance so that you know how to handle location-specific spills.
- Mark the dilution container in the spill kit in advance to show how much disinfectant to add and how much diluent to add in addition, to avoid delays when the time comes to handle a spill.
- Keep a pair of shoes at the lab just for use in the lab. If you routinely change shoes when you arrive at the lab and change back when you leave for the day you won't track everyday contaminants to your automobile or home, and if you need to remove your "lab" shoes because of spill contamination you will still have shoes available to leave the lab.
- Conduct periodic hands-on drills with volumes of spilled water similar to fluid volumes in use in the laboratory to ensure that all laboratory staff members are well-experienced in the location of the spill kit and in spill handling. Practice clean-up in typical and atypical spill situations.

Please use the links to see their full-page versions.

	Tenter .	Biona (Islanding o	zaro spin Response M d'caliceta, basi, Rangi al later (20 530 752 540) later for taris d'independent mension	ARTIK Ing EMBI	
Salarty seen of Salarty seen of Salarty seen of	Spiller Chateria	Spill Location. Spill Valuese Where Application	Appropriate PTE	Perilinkary artises	Wate dispiral and failure up
No.(1914)	Monotoxia Agente unter no intercesso an palhagene protectal lo function or ether maximum, recondensati concentratio, concept fronto, and non-infections vectores, anote marenen bait e uper culture media that have been to connect with 651 Agents		Lask court, glavets, siye prosection	Conduct rate accessionary)	Depend wants in their autocaus tags or sharps consumers, autocaus the tags and illusion to lendid, require a sharp point from Safety tarsies, wells therapical tarbits (Office of incoder and chan-up results)
Numero de socialmente a presente source in inderen Jució es reformánidad pel timos, presente source indereste de participantes agente har de com- siderativa de participantes agente har de com- siderativa de la companya de la companya de la com- nection de la companya de la companya de la companya indereste de la companya, talante, en anciente source de la companya, talante esta companya tempente de la companya de la companya de la companya aporte de la companya de la companya de la companya aporte de la companya de la companya de la companya aporte de la companya de la companya de la companya aporte de la companya de la companya de la companya aporte de la companya de la companya de la companya aporte de la companya de la companya de la companya aporte de la companya de la companya de la companya aporte de la companya de la companya de la companya de la companya aporte de la companya de la companya de la companya de la companya aporte de la companya de la companya de la companya de la companya aporte de la companya de la companya de la companya de la companya de la companya aporte de la companya de la companya de la companya de la companya aporte de la companya de la companya de la companya de la companya de la companya de la companya de la companya de la companya de la	destopper safety califyri, 130et	Last-star or faces greet, double gloves, progles or face shreld	Geoduit ise assessment ⁴	Explore watte in red thedical watte begalaty stehacard sharps cardianers, transport closed b	
	Numeri ar non-human pranata source materials	Purrupcul selvin cabinet, <32ml		Genduct Init accounters, ⁶ monthy Ballogical Safety Office	To a medical wants accumulation ste, permanent chipal charge spectrament and doording potential surfaces, respect a charge potential from Safety
	In laboratory, installe of BSI.] 6	Descute the laboration, solide the Bungloot Safety Office, conduct rook assessment, ¹ wait 50 minutes Baffere chain-up	Tervice, some hundput territ child of celevical	
	Decisivenul III simplifyer of Taulo goes, Koultingto refigeration gogies of Taulo goes, Koultingto gogies of Taulo goes, Koultingto	Lath cost or Tavel gover, double gives, gragies or Tave there, and a longing		Namile weater as described above for other BCD Agents, descentenistic the web's intenies of the web, names Bangging Safety Office of mean or multip, and medical Safety of	
	T public area	rauge dar to pintan displays	Transaction them even, chosen's from transfer, resulting the discongrame Safettes Offices, completer rest, assessmenter, ¹ world '20 minutes, before chosen and	Deputit water in red Anahor water lags an bahasan jubapa persenen, transport doeld is a metal a water subartation only, persen ourse analy conserver and bahashor search software, request a doeps policit from baha berrare, restrict bahagooi bahas (dhar at size master)	
BGJ/PSJ simul bravelsika prilogeni	Determ and year RC2 agents designated in Car Determination and 1200 Rpp, D as presentance annual transmission pathogens, "a not entitle programmers and proporting secondary, and an vestiment factor release programmers, were materials that have been to contact with these agents	ł	Solid Yurit bit cast or Tores gover, dealer glocer, for share or pagine, and a professional to restad respective (at back NVL)	Execution This reductions of some areas, disart future traffic, south the Recongrad Julies Office, conduct rise execution and RE resource before Union up	Number wante au described wissen for inter NCJ agents, webby Bologens Laboy Office of classes results, and medical follow-up
453,993.3		ana .	As between and and pro-approved by the incentional Bouahers (another		Control Broughting Committees

Consider a first part of a considered gene to interest a result of point opartition of the gal based of mean angle of the gal and an anternation of a carbon, among and a mendian application of detrollers to beneficing point opartition of the gal based. As a financial or the carbon of a carbon of the mean carbon of the based based and set the transmission of the carbon of the

Biohazard Spill Response Matrix [2]

Biohazardous Spill Clean-up

Contract of COLD Optim Order Difference of the provide state of the second st

Biohazardous Spill Clean-Up [3]

Contact

Biological Safety Office

biosafety@ucdavis.edu 530-752-1493 FAX: 530-752-4527

More information

https://safetyservices.ucdavis.edu/biological-safety-staff-listing [4]

Related content

1. Biohazard Incident Report

Copyright @2015 The Regents of the University of California, Davis campus. All rights reserved.

Source URL (modified on 08/24/17 02:59pm): https://safetyservices.ucdavis.edu/safetynet/biological-and-biohazardous-spill-response

Links

- [1] https://safetyservices.ucdavis.edu/form/biohazard-incident-report
- [2] https://safetyservices.ucdavis.edu/sites/default/files/documents/Biohazard%20Spill%20Response%20Matrix.pdf
- [3] https://safetyservices.ucdavis.edu/sites/default/files/documents/Biohazardous%20Spill%20Cleanup.pdf
- [4] https://safetyservices.ucdavis.edu/biological-safety-staff-listing

Biohazardous Spill Clean-up

- 1. If this is a moderate to high hazard spill reportable to the Biological Safety Office before clean-up (through the EH&S main number 530 752 1493), have you reported it?
- 2. Have you confirmed that appropriate PPE is available?
- 3. Have you checked yourself and others nearby the spill for spatter or shoe contamination?
- 4. Have you alerted the lab personnel and passersby (for spills in corridors) and evacuated the lab if appropriate?
- 5. Have you located the spill kit and verified that you have everything you need?
- 6. For spills outside of the biological safety cabinet, have you allowed 30 minutes settling time?
- 7. Are you trained in biohazardous spill clean-up?

If you answered "yes" to questions 1-7 and it is appropriate for you to clean up the spill, you may proceed as outlined below:

- A. Wear appropriate PPE to clean spills.
- B. If the spill involved broken glass, pick up the large pieces with the forceps or egg tongs and dispose in a hard-walled sharps container. Handle with care!
- C. Distribute paper towels around the periphery of the spill, then towards the center. Use the forceps or egg tongs to push paper towels into recesses where spilled material may have flowed.
- D. Dilute your disinfectant to the appropriate concentration in a spray bottle (if available).
- E. When the spill is fully covered with paper towels, spray or very carefully pour 10% bleach or other approved disinfectant on the paper towels. Avoid generating further aerosols or flooding the spill so much that untreated material may flow.
- F. Allow at least 30 minutes contact time.
- G. Pick up the paper towels with large forceps or egg tongs and put them in the appropriate waste bag. Change gloves and put used gloves in bag as well. Avoid direct contact with the contaminated paper towels, even with gloved hands.
- H. Spray or carefully pour 10% bleach or other approved disinfectant on the surface residue. Wipe up the residue with paper towels and place in appropriate bag. Small bits and pieces of broken glass should be entrained in the wet paper towels and discarded into the waste bag. Pieces too large or heavy to entrain must be discarded in a sharps container.
- I. Repeat step "H" at least once.
- J. Seal and transport the waste collection bag to the appropriate autoclave or medical waste accumulation site.
- K. If broken glass was disposed in a sharps container, seal the container permanently, decontaminate the exterior with the sprayed liquid disinfectant, and transport the sealed container to a medical waste accumulation site or request a sharps pickup on the Safety Services website (Davis campus)
- L. Clean and disinfect the forceps or egg tongs and any other non-disposable items before returning them to the spill kit. If possible, autoclave the forceps or egg tongs before returning them to the kit.
- M. Report the spill to your supervisor and to the Biological Safety Office

Biohazard Spill Response Matrix University of California, Davis, Biological Safety Office, EH&S 530 752 1493

Highlight the rows that include the types of biohazardous materials your laboratory handles

Risk Group/Biological Safety Level of laboratory	Spilled Material	Spill Location, Spill Volume Where Applicable	Appropriate PPE	Preliminary actions	Waste disposal and follow-up
RG1/BSL1	Microbial agents with no infectious or pathogenic potential to humans or other mammals; recombinant constructs, cloning hosts, and non-infectious vectors, waste materials such as spent culture media that have been in contact with RG1 agents	All	Lab coat, gloves, eye protection	Conduct risk assessment ¹	Deposit waste in clear autoclave bags or sharps containers, autoclave the bags and dispose to landfill, request a sharps pickup from Safety Services, notify Biological Safety Office of incident and clean-up results
	Human or non-human primate source materials such as established cell lines, primary cell cultures, tissues, blood, and body fluids, infectious or pathogenic agents that cause disease in humans which is usually not serious and for which treatments are often available, viral vectors derived from agents capable of infecting humans; plasmids that include coding sequences for oncogenes, toxins, or virulence factors, and other recombinant constructs normally used at BSL2; waste materials such as spent culture media that have been in contact with RG2 agents or materials	Biological safety cabinet, <10ml	Lab coat or Tyvek gown, double gloves, goggles or face shield	Conduct risk assessment ¹	Deposit waste in red medical waste bags and biohazard sharps containers, transport closed bags
RG2/BSL2		Biological safety cabinet, >10ml	Lab coat or Tyvek gown, double gloves, goggles or face shield, and a surgical mask or professionally fit-tested N95 respirator to entrain droplets	Conduct risk assessment, ¹ notify Biological Safety Office	to a medical waste accumulation site, permanently close sharps containers and disinfect exterior surfaces, request a sharps pickup from Safety Services, notify Biological Safety Office of clean-up results
		In laboratory, outside of BSC		Evacuate the laboratory, notify the Biological Safety Office, conduct risk assessment, ¹ wait 30 minutes before clean-up	
		Discovered in centrifuge or refrigerator			Handle waste as described above for other RG2 agents, decontaminate the entire interior of the unit , notify Biological Safety Office of clean-up results, seek medical follow-up
		In public area		Evacuate the area, divert foot traffic, notify the Biological Safety Office, conduct risk assessment, ¹ wait 30 minutes before clean-up	Deposit waste in red medical waste bags and biohazard sharps containers, transport closed bags to a medical waste accumulation site, permanently close sharps containers and disinfect exterior surfaces, request a sharps pickup from Safety Services, notify Biological Safety Office of clean-up results
RG2/BSL2 aerosol transmissible pathogens	Enteric and viral RG2 agents designated in Cal- OSHA Standard 5199 App. D as potentially aerosol transmissible pathogens; ² viral vector preparations incorporating oncogene, toxin, or virulence factor coding sequences; waste materials that have been in contact with these agents	Any	Solid front lab coat or Tyvek gown, double gloves, face shield or goggles, and a professionally fit-tested respirator (at least N95).	Evacuate the laboratory or other area, divert foot traffic, notify the Biological Safety Office, conduct risk assessment, ¹ wait 30 minutes before clean-up	Handle waste as described above for other RG2 agents, notify Biological Safety Office of clean-up results, seek medical follow-up
RG3/BSL3	All	Any	As determined and pre-approved by the Institutional Biosafety Committee		itional Biosafety Committee

¹ Consider all risks that the uncontained agents or materials entail, determine whether your training is adequate to ensure complete clean-up of the spill and decontamination of all surfaces, determine whether an immediate response such as immediate application of absorbent material is needed to prevent escalation of the spill hazard

²e.g., Salmonella sp., Shigella sp., E. coli O157: H7, HIV in clinical samples, consult the Biological Safety website for the complete list

11/2/2010 sjb